

Infinity-Bar3.0 for Boost, individual adjustments for sizes

Thank you for buying an Infinity-Bar3.0 for BOOST!

There are 2 bar-sets available for BOOST:

- **Infinity3.0 50cm/ 21m for Boost** (Recommended for size 7.0, 9.0, 11.0, 13.0)
- **Infinity3.0 60cm/ 21+6m for Boost** (Recommended for size 15.0, 18.0)

Both bars work safely for all sizes with the settings they are delivered.

To optimize them perfectly for each size, we recommend to apply the following individual adjustments:

- **Winder position (effective bar-length)**

There are 3 possible positions for the steeringline to attach at the bar-end (winder)




Inside

outside

- **Safety-release travel (knot position on FLS-endline)**

This is how far the bar slips up towards the kite, when you pull the quick-release. It's better if this travel is adjusted shorter for smaller kites. For this there's a knot on the FLS-endline which can be moved.



Data for all BOOST sizes

Size	Bar Setup		Flyinglines	FLS-Knot-Position [cm]
	Barsize [cm]	Winder position		
7.0	50	inside	21m	741
9.0	50	inside		840
11.0	50	outside		929
13.0	50	outside		1010
15.0	60	inside	21m + 6m extensions	1085
18.0	60	outside		1085

Good wind & ride safe!

Your Flysurfer team