

# PEAK

1.3 M<sup>2</sup> TRAINER

*... simply fun :)*



**FLYSURFER**  
KITEBOARDING

// EXTREMELY DURABLE  
// FUN IN THE LIGHTEST BREEZE  
// CLEAN 3-LINE SAFETY

---



<b>TECHNOLOGY</b>	Single-Skin Foil Kite
<b>FOCUS</b>	Powerkite, School, Fun
<b>SKILLS</b>	Beginner +
<b>SIZES</b>	1.3

The PEAK trainer is designed to be incredibly safe and easy to use. Perfect for children! The single skin technology makes it incredibly durable and tremendous fun in light winds. Playful and user friendly, it is the perfect first step into kite sports.

### „READY-TO-FLY“ PACKAGE CONSISTS OF:

- 1x PEAK Trainer Kite „Ready to Fly“
- 1x PEAK 3-line wrist safety
- 1x PEAK Trainer Gear Guide
- 1x PEAK Trainer Bag



## 1. SETTING UP

Open the wrist leash & attach it to your hand. Secure your kite at all times!



Now grab the bar and launch your kite.




## 2. LAUNCHING

Stand in a position so that your flying lines are about 45 degrees to the wind direction.

Check again if the area is clear and slowly take a few steps back.

Stop when the kite rises slowly. Control your kite while steering left and right.



### 3. SAFETY SYSTEM & RELAUNCH

Let go of the bar. The bar will slide towards the kite along the center leader line that is attached to your wrist leash.



Move towards the bar while pulling in the center leader line. Grab the bar while still holding onto the center leader line.



The kite will lose power and will slowly go down towards the ground. Wait till the kite has reached the ground before taking any further action.



Check that the lines are not tangled. Let go of the center line and grab the bar with both hands. You are now ready to relaunch.



#### 4. CARE

FLYSURFER kites are durable, very UV as well as salt-water resistant. With proper care, your kite may last even longer. Possible color changes of the cloth have no influence on the flight characteristics whatsoever and are not covered under warranty.

- Minimise the amount of time the material is exposed to the sun and flapping in the wind.
- Try to keep your kite dry and clean.
- Check all parts of the kite before each use.

#### 5. SAFETY NOTICE



Kiteboarding is a potentially dangerous sport, that holds risks for the athlete or the people around them. Incorrect use of this product may result in serious injury or even death of the user or third parties.



The user carries the sole responsibility for themselves and third parties when using this product. Every user should be qualified by a FLYSURFER Kiteboarding school or a dealer.



The product may only be used with original spare parts and may not be modified. The user must check their equipment for damage, especially on wearing parts, before each kite session.



Please read the entire Gear Guide thoroughly before using the kite and stick to the procedures mentioned. The safety guidelines are only guidelines and do not claim to cover every instance.

#### 6. SERVICE

The customer is king at FLYSURFER! Not only do we believe that the customer should be guided to the right product before a purchase, but it is also our view that the customer should be guaranteed 100% fun and function of their product over the entire lifespan of the product. With a worldwide network of dealers, importers, team riders, opinion leaders and of course the head office team, we want to offer you the best possible after-sales service. We will gladly inform you about the entire FLYSURFER product range, our services and any other questions you may have.

All new kites and bars which are privately purchased from FLYSURFER are covered by our **12-month Free-Repair Warranty. The time period for eligibility begins on the purchase date shown on your receipt.** Thanks to this unique service, which comes in addition to the standard manufacturer's warranty, your product is protected against almost any damages that may occur during the first year of use.

The service does not apply to kites that are used commercially (teaching, rental, etc) and does not apply to damage resulting from acts of negligence (e.g. contact with obstacles) or damage that has been done on purpose by the user.

**In case of a claim, please contact FLYSURFER Kiteboarding directly:**

✉ [support@skywalk.org](mailto:support@skywalk.org)

☎ +49 8641 6948 30

Further steps will be explained by our competent colleagues in the FLYSURFER head office on an individual basis. All infos about the repair process as well as the service order can be found online:

<http://flysurfer.com/repair/>

FLYSURFER Kiteboarding  
Brand of Skywalk GmbH & Co. KG  
Windeckstr. 4  
83250 MARQUARTSTEIN, GERMANY

☎ +49 [0] 86 41 69 48 - 30

🌐 [www.flysurfer.com](http://www.flysurfer.com)

✉ [info@flysurfer.com](mailto:info@flysurfer.com)



    
flysurferkiteboarding

